

## Storm Drain Marker Instructions

What you need:

- Drain markers
- Adhesive; one tube covers about 15 markers
- Gloves
- Broom or brush
- Newspaper (optional)

Where to place markers within the Fourche Creek Watershed:

- Positioned flat against the sidewalk just above the storm drain inlet, or vertically on the curb facing the street. Surface must be flat.
- At high visibility storm drains such as by sidewalks and intersections.
- So you can read the marker while facing the storm drain.



How to apply:

1. Sweep the surface. Surface must be dry and free of loose debris.
2. Apply adhesive following the pattern on the back of the marker. Wear gloves.
3. Stick it! Press down firmly and completely around the marker with gloved hands, or place newspaper on it and step down. Adhesive should come out around the edges, forming a complete seal.
4. Take photos of you placing markers and share them with Friends of Fourche Creek at [www.facebook.com/fourchecreek](http://www.facebook.com/fourchecreek)



**Safety first!**  
**Stay off the street.**  
**Watch for cars.**

Questions?  
Dan Scheiman, Audubon Arkansas  
[dscheiman@audubon.org](mailto:dscheiman@audubon.org)  
501-244-2229